




OVEN PARTS

For Models: RBS305PDB17, RBS305PDQ17, RBS305PDT17, RBS305PDS17
(Black) (Designer White) (Biscuit) (S.Steel)

30" BUILT-IN
ELECTRIC OVEN
SELF CLEAN



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: RBS305PDB17, RBS305PDQ17, RBS305PDT17, RBS305PDS17


(Black) (Designer White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	3		Hinge Receiver	26	4452234	Back, Chassis
	8300651	Installation Instructions		4455605	Left Hand		4449809	Screw
	8300772	Use & Care Guide (Oven)	4	4448520	Bumper, Door	27		Liner, Oven (Not serviceable)
	8301758	Tech Sheet (Oven)	7	4455865	Top Chassis	29	4455636	Sensor
	8301927	Installation/Undercounter		4449809	Screw		4449154	Screw
	3191638	Safer Cooking Tips	9	4452158	Tube, Vent	33	4457117	Deflector, Vent
	8301928	Instructions		3196176	Screw	37	9759243	Thermostat (TOD) (Temp.) SPST
		Microwave Trim Kit	10	4452165	Lens, Light	43	9759713	Base, Chassis
2		Trim, Side (Right Hand)	11	4452368	Oven Light Assy	49	4448933	Retainer, Gasket
	4450844	Black Model	12	4452166	Bulb, Light		4449154	Screw
	8281236	Screw	14	9759060	Frame, Front	50	4451747	Cover, Back
	4450845	White Model		4449040	Screw		4449809	Screw
	4452120	Biscuit Model (Left Hand)	15	4450118	Nut	53	4449845	Support, Bracket
	4450847	Black Model	19	4455382	Gasket, Door		4449809	Screw
	8281236	Screw		4451478	Support, Insulation	55		Trim, Bottom
	4450848	White Model	20	4449809	Screw		4448477	Black Model
	4452121	Biscuit Model	21	4451605	Cap, Spacer		4448478	White Model
					Rail, Side		4452415	Biscuit Model
				4450579	Right Side		3400832	Screw
				4450580	Left Side	FOLLOWING PARTS NOT ILLUSTRATED		
				4448444	Grommet			
				4449154	Screw	INSULATION		
			22	9759481	Latch, Motorized			
				4449154	Screw		4449316	Insulation, Wrap
			25	4455641	Side, Chassis (R.H. & L.H.)		4450365	Insulation, Back
				4449809	Screw			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: RBS305PDB17, RBS305PDQ17, RBS305PDT17, RBS305PDS17
(Black) (Designer White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	4457127	Door Liner
2		Hinge, Door
	8300571	R.Side (White)
	8300572	L.Side (White)
	8300573	R.Side (Lt.Blue)
	8300574	L.Side (Lt.Blue)
	4449743	Screw
3	4449259	Glass, Inner
4	4451722	Insulation, Door
7	9759225	Glass, Inner


Illus. No.	Part No.	DESCRIPTION
13		Door Handle
	4448854	Black Model
	4448855	White Model
	4452860	Biscuit Model
14	4450813	Bracket, Handle
	3400832	Screw
	4451040	Screw
15		Assy, Door Glass
	8300903	Black Model
	8300899	White Model
	8300894	Biscuit Model
	8300895	S.Steel Model
16	9759229	Bracket(2nd glass)

Illus. No.	Part No.	DESCRIPTION
17	9759230	Bracket(3rd Glass)
19	4457103	Shield, Heat
	4449809	Screw
20	4457132	Retainer, Glass
	3400832	Screw
21	8300820	Seal, Door Top
22	4457114	Shield, Heat (Btm)
23		Retainer, Clip
	4450863	Black Model
	4450864	White Model
	4452119	Biscuit Model
	4449743	Screw
24	9759228	Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: RBS305PDB17, RBS305PDQ17, RBS305PDT17, RBS305PDS17
(Black) (Designer White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
2	4456103	Element, Broil
	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
6	4448717	Rack, Oven
	9759322	Pad, Rack
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RBS305PDB17, RBS305PDQ17, RBS305PDT17, RBS305PDS17
(Black) (Designer White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
1		Control Panel Assy. W/Membrane Switch
	8300450	Black Model
	8300449	White Model
	8300535	Biscuit Model
	8281179	Screw
2	4451034	Gasket, Control Panel
3	8301919	Assy, Control
	4449745	Screw
	3400832	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: RBS305PDB17, RBS305PDQ17, RBS305PDT17, RBS305PDS17
(Black) (Designer White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
	4449040	Screw
2	4455178	Elbow, Vent-Top
3	4457289	Blower
4	4451758	Block, Foam
5	4455177	Elbow, Vent-Bottom

Illus. No.	Part No.	DESCRIPTION
11	4449868	Block, Terminal
	3400080	Screw
13	4448549	Vent, (Control Panel)
	4450038	Screw
14		Side, Control Top
	4451597	Right
	4451598	Left
	4449809	Screw

Illus. No.	Part No.	DESCRIPTION
15	9759135	Back, Control
	4449809	Screw
16	4450551	Cover, Top Rear
	4449809	Screw
18	4450554	Cover, Top Front
	4449809	Screw
19	4451985	Suppressor

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: RBS305PDB17, RBS305PDQ17, RBS305PDT17, RBS305PDS17

(Black) (Designer White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

72017	White
261869	Cord Brown
72032	Black

PAINT, SPRAY

350930	White
261900	Citrine White
830864	Black

ADHESIVE

591014	Adhesive Loctite (1/3 oz.)
482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SPLICING WIRES--25FT.

LENGTH

242828	Wire (12 Ga. 150 c Black)
242820	Wire (14 Ga. 150 c Black)
242821	Wire (14 Ga. 150 c Blue)
242822	Wire (14 Ga. 150 c Brown)
242830	Wire (14 Ga. 200 c Brown)
242823	Wire (14 Ga. 150 c Green)
242824	Wire (14 Ga. 150 c Orange)
242829	Wire (12 Ga. 150 c Red)
242825	Wire (14 Ga. 150 c Red)
242831	Wire (14 Ga. 200 c Red)
242826	Wire (14 Ga. 150 c White)
242827	Wire (14 Ga. 150 c Yellow)
242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

WIRING HARNESS PARTS

8301400	Harness, Wire (Main)
4450952	Conduit
4448664	Clamp
4449809	Screw
112432	Nut
4450800	Screw, Ground
4451761	Support, Wiring
4454842	Tie, Cable
4452222	Spacer, Harness

Miscellaneous

814381	Pin Hinge Kit
4448950	Screw, Install (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST